

DIESEL PURGE PROCEDURE IS SIMPLE.

To start, you'll need:

- Screwdrivers
- Glass jar (16 oz.)
- 1/4" hose (supplied with purge kit)

1. Pour the DIESEL PURGE into the jar.
2. Disconnect the fuel line at the injection pump and connect one end of the 1/4" hose to the pump.
3. Disconnect the cigar hose on the end closest to the firewall.
4. Hold the free end of the 1/4" hose in the bottom of the jar of DIESEL PURGE.
5. Hold the loose end of the cigar hose in the jar. This recycles the purge that is bypassed by the injectors.
6. Start the engine and run it until the purge is gone (about 10 minutes). Stop the engine before the hose starts to suck air.
7. Remove the 1/4" hose from the injection pump and reconnect the fuel line and the cigar hose when finished.

NOTE: KEEP THE 1/4" HOSE IN THE PURGE. DO NOT SUCK AIR INTO THE SYSTEM.

